How to connect a serial console to an SGI Fuel?

Published 04/10/2009

Symptom(s):

How to connect a serial console to an SGI Fuel?
How to connect to the internal L1 serial port on an SGI Fuel?

Fact(s):

SGI Fuel
HyperTerm
IRIX Operating System

SGI Solution:

To connect a laptop running Hyperterm to the Fuel Console, connect a null-modem cable to serial port #1 on the Fuel and setup Hyperterm for the proper COM port for your laptop and use 9600,8,N,1,Hardware Flow Control. Set Emulation for Auto.

To connect to the internal L1 serial port, use same settings as above, but use a baud rate of 38400.

Answers others found helpful

- Create video format combinations using ircombine
- Aligning XVM partitions to match a LUN's stripe width
- IRIX® Support Policy and Support Modes

Additional Details

Creation Date	12/17/2008 12:14 PM
Last modification	09/22/2015 01:32 PM
Published Date	04/10/2009
Products	• Servers and Clusters • SGI Origin/Onyx • Origin/Onyx Server • Software • Legacy Software • Operating Systems • IRIX • Workstations • SGI Tezro • O2 • Octane
Categories	• Knowledgebase • Technical Solution